


# Lego 10258

# LONDON BUS

## LED INSTALLATION GUIDE





Detach the upper deck



Remove the side mirrors






Turn over the upper deck





Lower deck lights







Remove the red slope from both sides








Replace the clear orange plates by light parts




Put the parts back



Install the other light plates




Pass the long wire connector into the upper deck







Take off the roof





Upper deck light




Detach the front roof



Install the first light plate beneath the front roof




Remove 2 tiles at the back






Install the 1x4 light part beneath the 1x6 tile



Put the roof on top like this



Put the tiles back



Plug in the connector to the lower deck lights




Put the roof back








Front lights





Remove some parts





Separate the white plate from the headlights







Install the lights




Fix the wire and put the parts back




Put the parts back



Remove the left wheel









Lift the window



Remove some parts












Move the round clear tile to red brick light





Install the red brick light, through the hole




Press the wire gently by the brick separator




Put the parts back








Fix the wire by the long back plate




Rear lights



Remove some parts





Move the clear orange tile to light parts






Pass the left rear light and connector to the exit





Put the wire between the bricks







Loosen the parts by both hands











Loosen the parts













Upper deck connector




Female end



Pass the female end to the hole above the steps




Adjust the male end, both wires should be similar length to the bottom






Fix the wires by long black plates




Put the parts back



Select A. USB plug or B. Battery Box



A. Plug in 3 connectors to USB plug




B. Plug in 3 connectors to battery box



Relocate the 2x8 black plate







Connect the plug to upper deck



Plug in the USB / switch on the battery box and done!

