


Lego 10243

Parisian Restaurant



LED Installation Guide






A. 7 decoration lights



To light up the clams at the roof, replace the 1x1 square plates with the round 1x1 plates with lights









Pass the other round plate inside the building, install the other clam






For hanging lanterns at the back, remove the yellow cone bricks and replace with lights






For dining area at the front, replace 3 yellow round bricks with lights






Put the wire along the wall




B. 4 light plates




Install 4 plates for interior and entrance lights, remove 2 tiles first




Take off the entrance





Put the first plate (closest to the USB plug) under the red entrance



Put the second plate at the ceiling of ground floor



Before install first floor light, take off the ladder at the back first



The third plate



Put the ladder back



The fourth plate





USB plug at the back door



C. Street pole



Put the wire under the baseplate

Plug in and done!

