




Winter Holiday Train

LED Installation Guide








Train engine



Train engine light




Remove the clear plates




Install the first light plate




Install the second light plate




Open the roof




Install the black light plate beneath the roof



Detach the gold stick and move the wire behind the stick






Coal tender





Coal tender light






Remove the white tree pieces





Remove some parts









Replace the color bulbs with lights



Put the light string on the red plate



Put the parts back







Caboose




Caboose light



Remove the roof




Remove the red tiles




Remove the white tree pieces on both sides



Remove the windows





Replace the color bulbs with lights



Put the light string wire behind the seat




Put the white tree pieces back



Move other lights inside the caboose




Put the windows and red tiles back




Relocate the round parts on the roof




Install the black light plate and clear lights on both end





Pass the mini plug from the top to the door



Put the roof back and fix the wire from the ladder






Flatbed wagon with Christmas tree



Christmas tree light








Remove the color plates



Install the red light plate at the bottom first







Put the wire between blue lights under the green plate




Replace the green cone by light part







Remove the blue round brick




Push the bar down







Remove the bar and gear to avoid light wire broken




Remove the mini train




Attach caboose to flatbed wagon, maximize the angle between two carts




Remove some parts on one side




Align the caboose light wire on the flatbed wagon



Put the parts back






Put the blue round brick, mini train and Christmas tree back




A. Lego battery box


Attach the 4-stud plug to the battery box





B. AAA battery box





Switch on and done

