LEGO 10235

Winter Village Market

LED Installation Guide

GLOW BRICKS



Candy stand

Candy stand light





Baker’s stand

Baker’s stand light





Grill stand

Grill stand light





Replace the plate on the roof





Streetlamp



Separate the clear shell carefully



Streetlamp light



Bucket challenge

Bucket challenge light



Remove 4 colour plates

Install the light plate beneath the red roof



Install the colour plates

Replace the yellow brick of streetlamp

Carousel



Remove the canvas

Remove all colour plates on top



3

Remove 4 white plates on the column

Rounding board lights



Installed the colour plates on the top

Column lights



Install 4 white plate with lights on the column



Move 2 connectors to the roof

Battery case



Insert AAA batteries, install the battery case on the roof

Plug in the connectors to battery





Switch on and rotate the carousel by hand to make sure wire okay



Put the canvas back. Connect the plugs to USB



plug in the USB and done