



Installation Guide









Start from removing the cover at the back and get the red lighting tiles




Remove the shown parts and stick the lighting tiles with connector attached at the brake lights, remember the wires connecting to other lighting tiles should be facing at bottom



Remove the shown parts, move the remain lighting tiles to the left and assemble them




Place the wire at middle to be stable and less visible then you can restore all the parts




For the connector, it would be placed differently depends on which kind of power source you want to use

Move the connector to the driver seat if you want to power by battery



If you want to power by USB, please move the connector to the bottom of the car There's a hole right besides the engine



Now it's turn for the front, remove the white bars at the front light and replace the slopes by the lighting parts






Do the same procedure for the other side, then hide the wires in between them on top of the front logo area




For the remain lighting tile, open the front cover and move it inside the seat area Then stick it on the top as shown





To power by USB, connect the USB cable with the connectors at the bottom of the car



If powered by battery, connect the plugs with the battery case, then place the case on the seat

