


# Lego 10367

THE  
LORD OF THE RINGS

Balrog Book Nook

*Installation Guide*





Take lighting part A to replace the diamond on the magic wand






Take lighting part B, detach the head and shown partsof Balrog to assemble the lights on it




Replace the orange clip in the month, remove the black part on the side to move the remain lights to the back of the head then stable the wire by restoring the black part



Assemble the 1x2 lighting plate under the slopes



Replace the fire and the slope shown in red circle






Restore the dark grey tiles to cover the wires properly



Then replace the remain four flames and the part in the back






Plug the big flame back on the orange part in previous step



Assemble lighting part C1 on the back of the fire  
\*C1 has 9 round plates and C2 has 10






Assemble the lighting round plates evenly on the flame and place the wires right behind the orange parts so the wires would be hidden when watching at the front




Then assemble lighting part C2 on the other side





Assemble it by the similar way after the previous step



Put Gandalf back on the model, stable the wire by the 2x2 round plate under





At last, put Balrog back to the model, gather 4 connectors and connect with USB cable

