


LEGO 11371

Shopping Corner

Installation Guide







First of all, split the building by floors and assemble the lights to second and third floor



Take lighting parts A and assemble the lighting plates underneath the second floor as shown



Combine 1st and 2nd floor, the connector with short wire would be moved to 2nd floor by the stairway (red circle) and the lighting diamonds in blue circle would be moved outside



Replace the diamonds on the lamps by the lighting parts



Take away the grey top of 2nd floor and assemble lighting part B as shown




For the remain lighting plates, move them to the top and assemble them inside the bird house




Assemble lighting part C underneath the 3rd floor




For lighting part D, pick the lighting round plates at the end, assemble them under the pavilion cover




Assemble the 1x2 lighting plate underneath, hide the wire when restoring the blue part shown




Restore the pavilion cover, assemble the remain lighting plates underneath the 4th floor and hide the wire inside the gap



Connect the plugs and combine 3rd and 4th floor, hide the exceed wire and combined plug in the corner



Restore the grey roof top with connector pops out



Connect the plugs with lighting part A then restore the top floors



At last, replace the lighting lamppost and connect both plugs with USB cable

