


Lego 40809

Festive Gingerbread House

Installation Guide





Before assembling, split the house as shown




Turn to the front and remove the shown parts




Remove the black fireplace and replace the fire by the lighting part then assemble the 1x6 lighting plate at the spot in front door shown in red circle



Restore the 2x14 white plate back on the house and leave the lighting plate as the ceiling light of the 1st floor




Leave the remain lights to the 2nd floor and restore the white plate, the wire would be get through by the gap of the white plates




Stable the 1x6 lighting plate



On the other side of the house, assemble the 1x6 lighting plate at the end to the front door first



Again place the wire in between the studs carefully, leave one 1x6 lighting plate in first floor then restore the ceiling of first floor



Assemble the 1x6 lighting plate after the ceiling is recovered then restore the second floor




Assemble the remain two lighting plates on the 2nd floor and stable the wire in between the studs



Restore the whole house then you can take lighting part B



Assemble the lighting string on the shown side of the roof, then connect the plugs with the ceiling light



Assemble the lighting string on the other side and stable the wires by the round plates on the roof

